



WATER-WASHING AIR PURIFIER

MODEL NO.: KJG-180B

# OPERATION MANUAL

QINGDAO FUNGLAN

ENVIRONMENTAL & PROTECTION TECHNOLOGY CO., LTD

*We enjoy the health*

*Of our family*

Qingdao Funlan Environmental Protection & Technology Co., Ltd

Address: No.143, Zhuzhou Rd, High-Tech Ind Zone, Qingdao, China,  
266101

Tel: 86-532-88706627

Fax: 86-532-88706628

Website: [www.funlan.com](http://www.funlan.com)

E-mail: [fl@funlan.com](mailto:fl@funlan.com)

# COMPANY PROFILE


Qingdao Funflan Environmental Protection & Technology CO., Ltd is a high-new technology enterprise, which professionally engages in the research, development, manufacture and marketing about series of products in environmental protection of the purification and sterilization.

The branch offices are equipped under our main corporation that possesses a professional team which specializes in the design and manufacture of air-purified equipments for many years, and keep a long-term cooperation with many distinguished academician from top-ranking seat of learning and scientific research organization at home and overseas, therefore we have the formidable technical strength. Our quality management system has been awarded this certificate for compliance with the standard ISO9001:2000.

Since our corporation was founded, we are always insisting on the managing principle “**Honest, Practical, Innovative and Public Benefit**” and strictly executes national and international technical standard to satisfy the market demand with excellent products and service.

Qingdao Funflan strives to provide a clean, germfree and comfortable living space for the customers

## I . Control Panel



All buttons listed below are from the left to the right are:

First line: **Humidity**、**ON/OFF**;

Second line: **Timing**、**Anion**、**UV Lamp**、**Airflow**

### **Humidity:**

The default humidity value is 70RH. You can adjust humidity ranging from 25RH to 80RH; When the actual humidity is higher than presetting value more than 10 minutes, the humidity function will be off working automatically. When the actual humidity is 10RH lower than presetting value, it will resume working automatically.

### **ON/OFF:**

Power button, when press this button to start up the machine, the airflow runs at the low state.

### **Timing:**

To control working time from 1 to 9 hours.

Press this button, the clock symbol blinks, and the LED digital rises, you can choose to turn off the machine some hours later.

Under timing state, pressing on-off button will cancel the timer; pressing timer button again, the clock symbol blinks, you can reset the timer to start machine some hours later..

Timer can work in progression circle, press one time, 1h light blinks, press two times, 2h light blinks,....., press nine times, 9h light blinks.

### **Anion:**

Pressing this button, Anion symbol  $\ominus$  blinks, and ionizer starts working.


### **UV Lamp:**

Pressing this button,  Photo-Catalyst function starts working.

### **Airflow:**

Pressing this button, the airflow button  lights, the machine will work at low speed at the beginning. Pressing it again, the airflow speed (low, medium, high) can be changed circularly.

## II. Remote control :



### **Child-Lock:**

While the machine has been working by pressing this button  all the functions will be locked. Pressing any other button cannot change the working status.

Press this button again will unlock all the functions.

### **Sleep Mode:**

While the machine has been working if you press this button, the machine will run at the low speed state, and the lampion will darken. After one minute all the lights will automatically turn off except the symbol  which indicates the sleep mode.

### **Lampion:**

Pressing this button, the 7-color lampions will blink. Pressing it again, the lampions will be darken.



Pressing this button “+” “-”, you can setting humidity and timing.

**Note: The functions of other buttons on remote control are in accordance with ones on the control panel.**

### **III. Introduction for the Display Screen:**

*We use LED digital screen for showing all working state.*

Connect with the power supply, all lights will blink for 2 seconds, then will darken except for humidity display.

#### **i . Humidity Display:**

When the machine is connected with a power supply, the digital screen will show the current humidity.

Humidity scope: RH25% ~ 80%.

#### **ii . Water Ripple Display:**

When the machine is working, the “water” will ripples circularly.

#### **iii. Anion Display:**

When Anion function is working, the Anion symbols  $\ominus$  will blink circularly.

#### **iv. UV Display:**

When UV-Photocatalyst function is working, the UV symbols  will light.

## IV. Installation and attention

Make sure the power is off. Take out the auxiliary water tank and twist off the cap, fill water into the tank. Twist on the cap and set it in right place.




Attention: The machine should be connected with a power supply after two minutes at least since after the full water tank be placed in the right position. Otherwise, the machine can give a water alarm.

### ● Drain

Please change the water in time when it hasn't been used for a long time or is contaminated. The steps are as below:

- i .Turn off the power and unplug the machine.
- ii .Take the auxiliary water tank out.
- iii.Screw off and disassemble the upper body from the main water tank,lean the left upper body towards right side to loosen the clips which connects these two parts.Then take out water deflector and its base..
- iv.Empty the dirty water of the tank, and clean the tank. If necessary, you can also add some detergent into the water for cleaning purpose.
- v Replace all the cleaned parts back in the right position,then screw on the left side.
- vi.The machine needs cleaning every 3 months only.



## V. Maintenance

- The machine should be placed on a water level surface. When carrying, please hold both side of the bottom tightly and steadily.
- Make sure nothing heavy above the airflow outlet.
- Make sure no obstruction blocked up any inlet of the three sides for ventilation purpose.
- As the machine has humidifying function, if your room is already very moist please choose airflow at low speed state, or stop working of the machine.
- Unplug the machine when it doesn't need working.
- For after-service in case of damage, please go to the appointed agent for maintenance.
- Clean or replace filter: Take out the bodies and drain the water, take off and replace the filters. No need replacing the black humidifying sponge, as which can be cleaned by water.
- **The machine can give an alarm when the water is in shortage. If no water refilled, the machine will keep alarming for 1 minute and then power-off after 30 minutes. The alarm will automatically stop after filling water.**

## VI. Trouble Shooting:

Troubles	Possible Reason	Solution
Alarm	1. No water filled 2. Water not enough	Fill water
Stop working	1. Timing off 2. Humidity off 3. Power off 4. Misuse of remote control	1. Cancel timing function 2. Press on/off button 3. Check power 4. Check remote control and correctly use it.

## VII. Technical data

Product Name	Air Purifier
Model	KJG-180B
Voltage	220V
Power	27W
Airflow	290m <sup>3</sup> /h
Noise	≤32dB(A)
Tank Capacity	8L
Dimension	440mmx252mmx438mm

**Note:** please subject to the actual product if the accessories are changed; the technical data is subjected to the nameplate on the machine body.

## VIII. Accessory

- i . Main set (1 pc)
- ii . Operating manual (1 pc)
- iii. Remote control (1 pc)

**WARNING:**

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Prior to cleaning or other maintenance, the appliance must be disconnected from the supply mains.